

## Wetwall Ceiling Panel Installation Guide

Depending on your installation method, either the ceiling panel or the side panel should extend slightly beyond the other to prevent gaps at the corners where the two bullnose panels meet.



### Preparation

1. Store panels flat for at least 48 hours before cutting and installation.
2. Ensure the substrate is clean, dry, free from debris, and properly plumb and square.
3. Acceptable substrates include green board, cement board, and existing tile.

### Panel Adhesive & Sealant

1. Use Wilsonart<sup>®</sup> Panel Adhesive for bonding.
2. Use Wilsonart<sup>®</sup> Coordinated Sealant for corners and seams.
3. Do NOT use wood glue or general construction adhesives.

### Panel Installation

1. Cutting & Fitting: Measure and cut panels using a 40–80 tooth saw blade. Dry-fit ceiling panels first.
2. Light Fixtures: Use a hole saw or router for cutouts.
3. Surface Prep: Clean the back of panels with denatured alcohol and a clean white rag.
4. Spacing: Maintain a 1/8" gap around the ceiling perimeter for expansion.
5. Adhesive: Apply vertical beads spaced 8–10 inches apart without touching.
6. Installation: Press firmly and use a J-roller.
7. Support: Brace panels if needed until adhesive cures (24 hours).
8. Finishing: Seal all edges and corners with coordinated sealant.

**Need Help?** Contact Technical Services: 800-433-3222